

Einbauwuchtkopf Typ ab

Antrieb Ø42, Klemmflansch, ohne Körperschallüberwachung

Typ	Art. Nr.	Kapazität [gcm]	L [mm]	ØD [mm]
ebz042-115-0200-ab	???	200	123	42
ebz042-115-0435-ab	???	435	123	42
ebz042-130-0250-ab	???	250	138	42
ebz042-130-0545-ab	???	545	138	42
ebz042-145-0300-ab	???	300	153	42
ebz042-145-0655-ab	???	655	153	42
ebz042-160-0350-ab	???	350	168	42
ebz042-160-0765-ab	???	765	168	42
ebz050-115-0400-ab	???	400	123	50
ebz050-115-0700-ab	???	700	123	50
ebz050-115-0800-ab	???	800	123	50
ebz050-115-0850-ab	???	850	123	50
ebz050-130-0500-ab	???	500	138	50
ebz050-130-1065-ab	???	1065	138	50
ebz050-145-0600-ab	???	600	153	50
ebz050-145-1275-ab	???	1275	153	50
ebz050-160-0700-ab	???	700	168	50
ebz050-160-1490-ab	???	1490	168	50
ebz060-115-0725-ab	???	725	123	60
ebz060-115-1595-ab	???	1595	123	60
ebz060-130-0925-ab	???	925	138	60
ebz060-130-1200-ab	???	1200	138	60
ebz060-130-1995-ab	???	1995	138	60
ebz060-145-1100-ab	???	1100	153	60
ebz060-145-2395-ab	???	2395	153	60
ebz060-160-1300-ab	???	1300	168	60
ebz060-160-2795-ab	???	2795	168	60
ebz070-115-1225-ab	???	1225	123	70
ebz070-115-2645-ab	???	2645	123	70
ebz070-130-1525-ab	???	1525	138	70
ebz070-130-3305-ab	???	3305	138	70
ebz070-145-1825-ab	???	1825	153	70
ebz070-145-3965-ab	18767	3965	153	70
ebz070-160-2150-ab	???	2150	168	70

